

VRSC maintenance schedule

item serviced	procedure	first service	5000	10,000	15,000	20,000	25,000
engine oil and filter	replace	X	X	X	X	X	X
oil lines and brake system	inspect for leaks	X	X	X	X	X	X
air cleaner	inspect, service as needed	X	X	X	X	X	X
tires	check pressure, inspect tread	X	X	X	X	X	X
clutch fluid	check level and condition	X	X	X	X	X	X
rear belt and sprocket	inspect, adjust belt	X	X	X	X	X	X
throtte. Brake, clutch controls	check, adjust, lubricate	X	X	X	X	X	X
jiffy stand	inspect and lubricate	X	X	X	X	X	X
brake fluid	check levels and condtion	X	X	X	X	X	X
brake pads and discs	inspect for wear	X	X	X	X	X	X
spark plugs	inspect		X		X		X
	replace			X		X	
electrical equipment and swithches	check operation	X	X	X	X	X	X
front fork oil		replace every 30, 000 miles					
steering head bearings	adjust	X				X	
rear fork bearings		nspect every 30,000 miles					
valve lash	adjust	adjust every 12,000 miles					
cooling system	inspect, clamps, coolant freeze point	X		X		X	
radiator	clean	X	X	X	X	X	X
critical fasteners	check tightness	X		X		X	
battery	check battery and clean connections	perform annually					
road test	verify component and system functions	X	X	X	X	X	X